

African logistics does not stop at borders — and neither does OverhaulOS. The platform was designed from day one as a continental network: when your truck crosses into another operating country, coverage follows it automatically.

HOW IT WORKS ACROSS A BORDER

- ▶ Your Controller is notified the moment a truck enters another operating country.
- ▶ A breakdown there is dispatched by the local OverhaulOS network to a local verified mechanic.
- ▶ The driver's app works identically — same buttons, same tracking, local language support.
- ▶ The mechanic is paid locally in local currency by OverhaulOS.
- ▶ The job draws from your same prepaid balance — each country has its own fixed price list, no FX inside a job.

COVERAGE & CURRENCIES

Country	Status	Local currency
Namibia	LIVE	NAD — Namibian Dollar
Zambia	LIVE	ZMW — Zambian Kwacha
South Africa	Launching soon	ZAR — Rand
Botswana	Launching soon	BWP — Pula
Zimbabwe	Launching soon	USD — US Dollar
Mozambique	Launching soon	MZN — Metical
Angola	Launching soon	AOA — Kwanza



WHAT YOUR TEAM EXPERIENCES

- ▶ **CONTROLLERS** – a country-entry alert, then business as usual: same map, same job cards.
- ▶ **DRIVERS** – nothing new to learn. The same BREAKDOWN button works in every country.
- ▶ **ACCOUNTS** – one prepaid balance, per-country price lists. Cross-border jobs are clearly flagged per country.

COMMON QUESTIONS

Q: Do I pay in foreign currency?

No. Mechanics are paid locally by OverhaulOS from your prepaid balance; each country has a fixed price list, so there is no FX inside a job.

Q: Does my driver need a different app or SIM?

No. The app switches network automatically. Offline reporting covers signal gaps near borders.

Q: What if the truck breaks down in a country you haven't launched yet?

Our 24/7 support line will still assist with referrals, but in-app dispatch applies to live countries.

Planning a new corridor? Tell us your routes – corridor demand is a key input for which country we activate next.
fleets@overhaulos.com